

# Laser Barcode Scanner User Manual V1.0

This is a easily use manual for laser barcode scanner, if you need the more details about how to use, please download from our official website or get the manual from distributors.

## Tutorial set

Scan need barcode function

For example: the scanner is set to Factory Default, USB-HID, Enter & Line”.

### 1. Factory Default



### 2. Enter & Line



## Data Interface Mode



USB-HID(\*)



USB-COM



RS232



PS2

Note: USB-HID, USB-COM in the USB interface  
PS2 in the PS2 interface  
RS232 in the RS232 interface

## Scanning Mode



Manually(\*)



Automatic successive



Automatic flashing

## Factory Default



Note: the asterisk(\*) to the factory default

## Software version number

